

# wood slat wall panel installation

J THOMAS HOME

Congratulations on your slat wall purchase! This guide will walk you through the installation process, so you can enjoy your wall's new look right away.

## What's Included:

Your set of J Thomas Home Slat Wall Panels (2 per box)

## Natural Wood Beauty:

Heads up! Since these are made with real wood veneer, there might be slight variations in color and grain between each slat and panel. It's nature's way of making your wall one-of-a-kind!

## Additional Items You May Need :

Construction adhesive  
Drywall screws (1.4-inch black for the black panels )  
Cutting tools: A sharp saw and a craft knife (just in case)

## Need a Hand? We're Here for You!

If you have any questions about installation or need some extra advice, feel free to contact the amazing J Thomas Home team at:

Phone: 913-353-4283  
Email: [customerservice@jthomashome.com](mailto:customerservice@jthomashome.com)  
Website: [www.jthomashome.com](http://www.jthomashome.com)

## Forget to order end pieces for your complete look?

Get a complete look with one of our slat wall end pieces so your wall looks as finished and sophisticated as possible. Shop end pieces on our website at [www.jthomashome.com](http://www.jthomashome.com)

## get featured!

Send us an Instagram photo to get your space featured on our social media! Who knows, you might even end up on our website!



## simply unbox and install your new slat wall panels

Skip the prep work! We've taken care of the finishing touches, so you don't have to. These panels come pre-finished for a beautiful look right out of the box.

### 1 Cut / Trim (as needed):

Need to cut your panels to fit your space? No problem! Use a sharp saw to cut across the slats and a craft knife to cut the felt backing lengthwise.

**Important note:** Before moving on to step 2, be sure to pre-cut any openings for outlets, switches, or other features you may need.

### 2 Glue It (optional):

Prep the glue by cutting the tip and insert it into the dispenser. Then, spread the construction adhesive in even strips directly onto the felt backing of the panel, leaving a 2-inch gap around the edges to prevent squeezing out during application.

### 3 Secure It with Screws:

Once glued, put the panel into place and screw the black drywall screws directly through the felt and into the wall to ensure a secure hold. Remember, the panels interlock, so the screw holes will be hidden behind the slat of the previous panel.

**Please note:** Once all panels have been installed, if you purchased our coordinating slat wall end pieces, now is the time to install them. Simply cut to size and secure with finishing nails or construction adhesive for a flawless finish.

### 4 Relax and Enjoy!

High five yourself! You've successfully installed your new wood slat wall panels. Now comes the best part—admiring your handiwork!